

AIRBAG HEAT-SEALED TYPE PACKAGING & INFLATING INSTRUCTIONS




HEAT-SEALED TYPE INFLATABLE AIRBAG

AIRBAG HEAT-SEALED TYPE PACKAGING & INFLATING INSTRUCTIONS

By Mike Josiah and the Technical Staff at UniNet



1. Place the cartridge in the correct size bag.



2. Heat seal the bag in the area indicated by the red line.

Do not use excessive heat. Just a short time interval works fine.



3. Set the pressure on the air gun to 12 PSI.

Insert the air gun nozzle into the center fill port of the bag as shown.

Fill the bag until fully inflated.



4. Place the cartridge in the box. When in a properly sized box, there is no need for any further packing materials.